

O-TAP B installation guide for



1. Locate and remove the MAP sensor on the intake manifold.



2. Choose a supplied nozzle that suit your needs and screw it onto the O-TAP B body. There are 3 locations for installing the nozzle. You may install maximum 3 nozzles at the same time if needed. Use the supplied screws to seal the unused channels. Add a drop of screw-lock on each nozzle or screw for maximum security.
3. Secure the boost tube onto the nozzle. Extra tube clamp might need for maximum security.
4. Lubricate the O-Ring on the MAP sensor with engine oil and install the sensor into the O-TAP B.



5. Lubricate the O-Ring on the O-TAP B body with engine oil and secure both sensor and the O-TAP B into the intake manifold with the supplied long screws.

